


#### **INSTALLATION INSTRUCTIONS**

# AP-AURORA-LED





#### **Safety & Warnings**

- 1.Carefully read all instructions before proceeding.
- 2. Follow all national and local electrical codes when installing.
- 3. This product should be installed and serviced by a qualified, licensed electrician.
- 4.Use only with a compatible Class 2 LED driver. This product has not been tested with LED drivers that do not meet Class 2 voltage and energy limitations.
- 5.Do not install in wet areas. Suitable for dry and damp locations only.
- 6.Ensure the power is turned off before installing or servicing the fixture.
- 7.To prevent fire and overheating, ensure all connections are secure.




#### **WARNING: ELECTRIC SHOCK HAZARD!**

Serious injury or death may occur. Before installation or servicing, turn off the power at the circuit breaker.



## **Standard Suspension Diagram**



#### **External Components**

- 4" Square/Octagonal J-Box
- Wood Screws, #10, 1.5" long

Not Included.

#### **Tools**

- Drill
- #2 phillips bit
- Wire strippers
- 1/16" Hex Key (for Ceiling)
- 5/64" Hex Key (for Joining)

Not Included.

#### **Specifications**

Input Voltage / Frequency: See product label

Rated Power: See product drawing

Ambient Temperature: -4° – 120°F (20° – 50°C)


**Environment:** 

Dry and damp locations







### **INSTALLATION**



1 Secure the J-Box and mounting bracket with screws.



3 Attach and secure the canopy to the bracket with screws.



A.Connect the power wires and secure them with a connector cap. B.Choose the color temperature when the fixture is powered off.



4 Press the suspension pin to adjust the fixture height.





### **WIRING DIAGRAM**

