



SAFETY INSTRUCTIONS

1. Do not use outdoors. 2. Equipment should be mounted securely in locations and at heights where it will not be readily subjected to tampering by unauthorized personnel. 3. Do not mount near gas or electric heaters. 4. Cap unused wires with enclosed wire nuts or other approved method. 5. Do not use this equipment for anything other than its intended use. 6. The use of accessory equipment not recommended by the manufacturer will void product listing and warranty and may cause an unsafe condition. 7. Use caution when servicing batteries. 8. Any service on this equipment should be performed by qualified personnel only. 9. Make sure wire terminations are secure and leads are properly tucked in appropriate wire channels. **CONSULT A QUALIFIED ELECTRICIAN BEFORE INSTALLING**



Caution:

Disconnect AC power before servicing and installation. All electrical connections must be in accordance with NEC/CEC or your local code.

INSTRUCTIONS STEPS

- 1.** Remove the cover plate and set aside.
- 2.** Insert ends (for Straight Connector) of connector or the end (for Live End Connector) of the connector into the ends of track (Ground Contact must line up with Polarity Groove of track.) Secure track by tightening lock screws at the tip of connector until snug. **DO NOT OVER TIGHTEN.** This may distort track.
- 3.** Mount Live End to junction box by passing power supply wires through center hole of mounting plate and secure to the junction box by using two screws (provided by others) through the two slots on the mounting plate. When using conduit to supply power, install the conduit, or flex to the Live End using an appropriate connector
- 4.** Cut and strip wires from box and connect black wire from box to brass screw terminal. Connect white wire from box to nickled-plate screw terminal.
- 5.** Fasten ground green wire to the green ground screw. Replace cover on live end and tighten screws.

