

# LED-HU-22

## INSTALLATION INSTRUCTIONS

#### SAFETY PRECAUTIONS

For safety, read and understand instructions completely before starting installation. Electricity should be turned off at the fuse or the circuit breaker box before installing the fixture. All electrical connections must be in accordance with N. E. C. or your local code.

## CONSULT A QUALIFIED ELECTRICIAN BEFORE INSTALLING

#### SURFACE MOUNTING


- 1. Locate the desired position for puck light.
- 2. Install the mounting can to mounting surface using two screws supplied.
- 3. Snap housing into the mounting can.
- 4. Connect the puck light to the 3-port adapter.
- 5. Connect the AC cord to an outlet.


#### **Recessed Mounting**

- 1. Drill a 2.5" hole in the desired location.
- 2. Feed wires through hole and the push housing into hole. The housing's spring clips will snap to the edge of the hole to hold puck in place.
- 3. Connect the puck light to the 3-port adapter.
- 4. Connect the AC cord to an outlet.


#### **Technical Specifications for Driver**

Output Voltage: 12VAC Output Power: 75VAC Input Voltage: 120VAC Frequency: 50/60Hz









\*1 puck - Driver sold separately / \*\*\*3-pack - Driver is included

## CAUTION: RISK OF ELECTRIC SHOCK DISCONNECT POWER BEFORE CONNECTING THE FIXTURE. FAIL TO DO SO MAY PERMENANTLY DAMAGE THE LEDS.

### WARNING: DO NOT REMOVE OR ATTEMP TO REMOVE LEDS.